

### Tools You'll Need

Texture Plus® products are easily installed using tools found in almost everyone's toolbox. To complete a wall, we recommend using:

1. Drywall screws
2. Construction Adhesive/Glue (we recommend PL® Polyurethane Premium Construction Adhesive)
3. Screwdriver (battery-operated/ electric preferred)
4. Sandpaper or sanding block
5. Caulking gun
6. Texture Plus® color-matched caulk



### How To Miter A Corner Using Texture Plus® PANELS

First, set a table saw blade to a 45-degree angle. Then, cut miter to the edge of a row of bricks. Next, take the remaining piece and rotate it 180 degrees to cut of the width of a 1/2 brick. Check the two pieces for final fit. Then take the first piece and apply/spread glue to the back of the panel. Fit the glued piece to the wall and screw it to the wall using dry wall screws. Fit the second piece and then glue and screw in place. Gently roll edges into each other with a hard rounded object. For a final finish, use Texture Plus® color-matched caulk to fill all screw holes and any gaps. Smooth the caulk and wipe away any excess (a wet rag works well) and finish the seams of the wall to complete the project.



set table saw



cut miter



rotate 180 degrees



check fit



apply adhesive/glue



spread glue on panel



fit glued piece & screw to wall



fit second piece



glue & screw in place



roll edges with a rounded object



fill screw holes/gaps



smooth



and finish