

Tools You'll Need

Texture Plus® products are easily installed using tools found in almost everyone's toolbox. To complete a wall, we recommend using:

1. Drywall screws
2. Construction Adhesive/Glue
(we recommend PL® Polyurethane Premium Construction Adhesive)
3. Screwdriver (battery-operated/
electric preferred)
4. Sandpaper or sanding block
5. Caulking gun
6. Texture Plus® color-matched caulk

Optional: hacksaw (for custom cutting)



General Installation Instructions - Texture Plus®

About Texture Plus® Panels

Texture Plus® is a high-density design and construction panel with more than 200 designs shipped around the globe. Based and manufactured in Long Island, New York, Texture Plus® leads the industry in creating high-impact panels with extraordinarily realistic dimensional textured surfaces appropriate for indoor or outdoor use. Texture Plus® panels do not absorb moisture and will not warp, rot or crack. The following instruction guidelines will help provide the best installation results for your next project.

Storing Texture Plus® Panels

Store Texture Plus® panels flat on a surface in order to avoid 'bowing'. If panels are stored in an upright position and do bow, lay them flat and they will self-correct.

General Installation Guidelines

Texture Plus® panels are installed using construction adhesive and screws. However, Texture Plus® panels may expand and contract with temperature changes and must be installed tightly. To minimize the effect of expansion and contraction, install the panels as tightly as possible and follow the storage and installation instructions carefully. First, install Texture Plus® panels on solid backing. Then run a bead of adhesive along the back of each panel and at each end. Make sure to spread the adhesive with a spackle knife or other appropriate tool. Use enough adhesive so that the entire surface of the cut edge at each end is covered. We strongly recommend use of construction adhesive and screws in every joint. All joints should be butt joints on straight runs and mitered joints in corners. Texture Plus® panels may require additional shimming and trimming for alignment. Finish seams with color-matched caulk available through Texture Plus.

Hot Weather Installation

If panels have been stored under hot conditions, allow panels to cool down to normal temperature before installation.

Cold Weather Installation

If panels have been stored at room temperature or cooler, you may install panels immediately.

Recommended Adhesive

We recommend PL Premium Polyurethane Adhesive or similar construction adhesive (rated for use on urethane).

Mechanical Fastening

Use either exterior or interior screws as appropriate for your installation.

Tools You'll Need

Texture Plus® products are easily installed using tools found in almost everyone's toolbox. To complete a wall, we recommend using:

1. Drywall screws
2. Construction Adhesive/Glue (we recommend PL® Polyurethane Premium Construction Adhesive)
3. Screwdriver (battery-operated/ electric preferred)
4. Sandpaper or sanding block
5. Caulking gun
6. Texture Plus® color-matched caulk

Optional: hacksaw (for custom cutting)



How To Cover A Wall Using Texture Plus® INTERLOCK PANELS

Start by creating a loose fit by joining pieces on the floor. Check the fit and sand the edges if needed. Use a hacksaw blade if you need to cut to accommodate wall obstructions and sand the edges to smooth. For best results, double-check the fit again. Then apply glue to the backs of the panels and screw into wall using drywall screws. Fit the next panel and glue and screw in place. Repeat until the row is complete. To begin the next row, offset the next row by 1/2 sheet to provide a more seamless effect. For a final finish, use Texture Plus® color-matched caulk to fill all screw holes and any gaps—even wide gaps. Smooth the caulk and wipe away any excess (a wet rag works well) and finish the seams of the wall to complete the project



create a loose fit



assemble pieces



cutout wall details



sand/smooth cut edges



check fit



glue and screw to wall



fit next piece



offset next row by
1/2 sheet



fill gaps with caulk



caulk seams to finish

Tools You'll Need

Texture Plus® products are easily installed using tools found in almost everyone's toolbox. To complete a wall, we recommend using:

1. Drywall screws
2. Construction Adhesive/Glue
(we recommend PL® Polyurethane Premium Construction Adhesive)
3. Screwdriver (battery-operated/
electric preferred)
4. Sandpaper or sanding block
5. Caulking gun
6. Texture Plus® color-matched caulk

Optional: hacksaw (for custom cutting)



How To Miter A Corner Using Texture Plus® PANELS

First, set a table saw blade to a 45-degree angle. Then, cut miter to the edge of a row of bricks. Next, take the remaining piece and rotate it 180 degrees to cut of the width of a ½ brick. Check the two pieces for final fit. Then take the first piece and apply/spread glue to the back of the panel. Fit the glued piece to the wall and screw it to the wall using dry wall screws. Fit the second piece and then glue and screw in place. Gently roll edges into each other with a hard rounded object. For a final finish, use Texture Plus® color-matched caulk to fill all screw holes and any gaps. Smooth the caulk and wipe away any excess (a wet rag works well) and finish the seams of the wall to complete the project.



set table saw



cut miter



rotate 180 degrees



check fit



apply adhesive/glue



spread glue on panel



fit glued piece and
screw to wall



fit second piece



glue & screw in place



roll edges with a
rounded object



fill screw holes/gaps



smooth



and finish

Tools You'll Need

Texture Plus® products are easily installed using tools found in almost everyone's toolbox. To complete a wall, we recommend using:

1. Drywall screws
2. Construction Adhesive/Glue (we recommend PL® Polyurethane Premium Construction Adhesive)
3. Screwdriver (battery-operated/ electric preferred)
4. Sandpaper or sanding block
5. Caulking gun
6. Texture Plus® color-matched caulk

Optional: hacksaw (for custom cutting)



How To Use Texture Plus® MOLDED CORNERS

Using An Overlaid Joint

First, finish the walls with Texture Plus® panels. Next, overlay the molded corner directly on top of the panel. Then apply glue to the backs of the panels and screw into wall using drywall screws. For a final finish, use Texture Plus® color-matched caulk to fill all screw holes and any gaps—even wide gaps. Smooth the caulk and wipe away any excess (a wet rag works well) and finish the seams of the wall to complete the project.



finish wall with TP Panels



overlay molded corner,
then glue & screw



use color matched
caulk to finish

Using A Butt Joint

First, finish the walls with Texture Plus® panels. Then, attach molded Texture Plus® corner to wall by applying glue to the backside of the corner and screwing into wall using drywall screws. Next, align a Texture Plus® **standard** panel (or trim an **interlock** panel) to the molded corner. Then apply glue to the back of the panels and screw into wall using drywall screws. For a final finish, use Texture Plus® color-matched caulk to fill all screw holes and any gaps—even wide gaps. Smooth the caulk and wipe away any excess (a wet rag works well) and finish the seams of the wall to complete the project.



screw & glue molded corner



align panel to corner
screw & glue



fill seams & holes



complete wall